

16 Channel Active Hub Instructions

Front Panel Description



Single Balun (Powered or Non-Powered) on the camera end can be wired directly into the hub or terminated to an RJ45 connection

Power LED for Unit
Power Toggle Switch

Back Panel Description

Camera output to DVR and camera number



Power Input

cams 1-4

cams 5-8

cams 9-12

cams 13-16

Green terminal blocks can be used to wire CAT 5 directly, or you can terminate 4 cameras at a time using RJ45 connectors.

Balun

To connect to camera




Screw terminals for CAT 5 or any kind of data wire

Brightness Control

Power LED for each camera

Brightness Control



Dip Switches to set transmission distance

Camera #s